

INTRODUCTION

Jointly developed by Avalon SteriTech and SoftBank Robotics, the solution combines the technology of AI-powered vacuum cleaning robot with an advanced bio-decontamination system to offer more effective and thorough routine for cleaning and disinfection.

Whiz Gambit is the first disinfection robot to achieve Performance Mark by SGS Hong Kong with proven efficacy to **eliminate >99% microbial bioburden**.

Whiz Gambit is a proud recipient of a number of international accolades:



Assembly Instructions

1. Ensure Whiz is switched on.
2. Align the Gambit with Whiz, hold the top part of Whiz with one hand and hold Gambit with another hand, and push the two units together.
3. Lift the Whiz handle slightly to let the top housing of Gambit pass under handle.
4. An audible “click” should be heard when the two appliances are assembled.



Filling Instructions

1. Switch off the Gambit and detached from Whiz.
2. Ensure the Gambit system is not connected to the power charger.
3. Drain the solution tank until it is empty. Then turn the drainage valve to its closed position.
4. Flip open the solution filler door.
5. Slowly fill the Gambit system with approved chemicals through the filler port filter.
6. Close the solution filler door firmly after filling.



Operation Modes

1. Ensure the Whiz is switched on and couple the Gambit system to Whiz.
2. Turn on the Gambit system by pressing the power button.
3. Wait 50 seconds for the Gambit system’s automatic boot up sequence to initiate.
4. If you want to manually override the automatic system, press the spraying nozzle manual button.

